



OnReal

使用説明書

內容物



OnReal
無線相機



使用說明書



micro USB
傳輸線



背夾



自黏膠




吸盤



磁鐵

快速了解 OnReal



Micro microSD
USB 插槽
連接埠

快門鍵

相機
狀態燈

充電
狀態燈


動作
感測器

鏡頭

麥克風

電源/
無線網路
按鍵

蜂鳴器



第一次設定只需要二個簡單的步驟

步驟一 確認將microSD記憶卡插入OnReal。

1. 於OnReal底部的microSD插槽。
2. 將microSD記憶卡金手指接點朝向鏡頭方向插入。
3. 記憶卡完全插入固定時會發出喀搭的聲音。



步驟二 充電電源

1. 使用隨附的 micro USB 傳輸線將OnReal連接至電源。
2. 充電指示燈變成綠色，表示你的OnReal已充飽電,充電中指示燈亮橘色。



啟動你的OnReal

1. 按住電源/無線網路按鍵來啟動你的OnReal。
2. 相機狀態燈會持續閃爍綠色。如果你的OnReal閒置超過50秒，你的OnReal將會自動進入關閉模式。
3. 之後要使用OnReal時，只要搖晃OnReal的動作感應器，OnReal 便會立即啟動。



拍攝相片

1. 按下快門按鍵。
2. 相機狀態燈會閃爍紅色且OnReal會發出嗶嗶聲。

拍攝影片

1. 按住快門按鍵1秒，發出嗶嗶聲並放開快門按鍵會開始長時間錄影。
2. 相機狀態燈在錄影時會持續閃爍紅色。
3. 再次按下快門按鍵停止錄影,且OnReal再次發出嗶聲。
4. 相機狀態燈會持續閃爍綠色。

拍攝短片

1. 按住快門按鍵1.5秒以上，發出第兩次嗶嗶聲時會開始短暫錄影。
2. 相機狀態燈在錄影時會持續閃爍紅色。
3. 放開快門按鍵會停止錄影,且OnReal再次發出嗶聲。
4. 相機狀態燈會持續閃爍綠色。

初次配對你的OnReal和手機 在你的OnReal上

1. 按下電源/無線網路按鍵來啟動你的OnReal
2. 再次按下電源/無線網路按鍵來啟動無線網路。在等待你的手機連線時，相機狀態燈會閃爍藍色3秒,並保持120秒連線狀態。

在你的手機上

1. 按下主畫面鍵，接著點選設定 > Wi-Fi。
2. 確定開啟 Wi-Fi，然後從清單中選取 OnReal 的名稱。OnReal 的預設名稱會類似 "OnReal...."。
3. 輸入預設的密碼12345678，然後點選加入。
4. 按下主畫面鍵，接著點選 OnReal 應用程式圖示。

microSD記憶卡容量已滿，狀態燈會顯示橘燈。

電池低電壓，狀態燈會持續閃爍橘燈。

產品規格

名稱: OnReal 無線相機

尺寸: 42mm x 42mm x 20mm

重量: 25g

影像解析度: 1080p FHD 影像

圖像清晰度: 8M

無線傳輸: 內置天線 802.11 b/g/n

影像連續播放與錄影: 1 hour

軟體支援: Android 4.0 或以上,
iOS 7.0 或以上

操作溫度: 32°F to 104°F (0°C to 40°C)

儲存溫度: -4°F to 158°F (-20°C to 70°C)

保固期間

OnReal 無線相機提供一年保固。保固範圍不包括因使用不當或產品刻意損壞。



OnReal

User Guide

Contents



OnReal
Wireless Camera



User Guide



micro USB
Cable



Clip



Viscose




Sucker



Magnet

Get to Know Your OnReal



Micro
USB
Port

microSD
Slot

Shutter button

Camera
status LED

Charger
status LED


Motion
sensor

Lens

Mic

Power/
Wi-Fi
button

Buzzer



Setting up your OnReal for the first time in two steps.

Step1. Insert microSD card.

Confirm that there is a microSD card inserted in your OnReal.

1. Find the microSD™ slot located at the bottom of your OnReal.
2. Insert a microSD card with the gold-plated side facing the same direction as the lens.
3. The card will make a slight clicking sound, when it's securely inserted.



Step2. Charge the battery

1. Connect your OnReal to a power source using the supplied micro USB cable.
2. The Charger status LED turns green, when your OnReal is fully charged.



Power on your OnReal

1. Simply press the Power/Wi-Fi button to power on your OnReal
2. The Camera status LED will keep flashing green. If your OnReal idles over 50 seconds, your OnReal will enter power-Off mode automatically.
3. For subsequent use, simply shake your OnReal by the motion sensor. And, it will instantly power on.



Take photo

1. Press the Shutter button.
2. The Camera status LED will flash red, and your OnReal will beep.

Record video

1. Press and hold the Shutter button until recording starts.
2. The Camera status LED will keep flashing red and green while recording. You'll also hear OnReal beep.
3. Press the Shutter button again to stop recording.
4. The Camera status LED will keep flashing green, and your OnReal beeps again.

Record video clip

1. Press and hold the Shutter button.
2. The Camera status LED will keep flashing red and green while recording. You'll also hear OnReal beep twice.
3. Release the Shutter button to stop recording.
4. The Camera status LED will keep flashing green, and your OnReal beeps again.

Pairing your OnReal and your phone for the first time.

On your OnReal

1. Press Power/Wi-Fi button to power on your OnReal.
2. Press the Power/Wi-Fi button again to turn on Wi-Fi. The Camera status LED will keep flashing blue for 3 seconds, and your OnReal enables Wi-Fi connection for 120 seconds.

On your phone

1. Press the Home button, and then tap Settings > Wi-Fi.
2. Be sure that Wi-Fi is on, and then select the name of your OnReal from the list. By default, the name will be something like "OnReal....".
3. Enter the default password 12345678, and then tap Join.
4. Press the Home button, and then tap the OnReal App icon on your phone or tablet.

The Camera status LED turns orange, when your OnReal microSD memory is full.

The Camera status LED keeps flash orange, when your OnReal battery is low.

Specifications

Model : OnReal Wireless Camera

Dimension : 42mm x 42mm x 20mm

Weight : 25g

Video resolution : 1080p FHD video

Picture resolution : 8M

Wireless : Internal antenna 802.11 b/g/n

Video streaming and record : 1 hour

Software support : Android 4.0 or above,
iOS 7.0 or above

Operating Temperature : 32°F to 104°F (0°C to 40°C)

Storage Temperature : -4°F to 158°F (-20°C to 70°C)

Warranty Information

OnReal Wireless Camera offers a 1-year limited warranty for hardware defects. Warranty does not cover problems caused by misuse or mistreatment of the product.